



Pipe size DEMO

How to measure the pipe diameter:



when you want to know the measure of a pipe you must measure the inside diameter of the pipe to know the correct pipe size.

Example: 4" pipe



Incorrect Measurement

The **outside diameter** of the PVC Pipe will result in the incorrect size.



Correct Measurement

The **inside diameter** of the PVC Pipe will result in the correct size.